

Installation procedure **STOP ID** XPM



Accessory

Special glue
Tags on backing paper
Installation tool

1. Preparations

Clean the area where the tag shall be installed thoroughly (free from grease and dust).
Remove the tag from the backing paper and place it upside down on the installation tool. Press the tag lightly into position. Make sure to avoid finger contact with the adhesive strip around the edge of the tag.



2. Application of special glue

Spread the glue* over the back of the tag, making sure that the yellow insert is completely covered. The required amount of glue depends on the size of the tag (see below)

Size 35 mm x 20 mm: 2 drops of glue
Size 46 mm x 28 mm: 5 drops of glue
size 64 mm x 38 mm: 10 drops of glue

* **Cyanoacrylate - Danger!**

Bonds skin and eyelids together in seconds. Keep away from children. R36/37/38 irritating to eyes, respiratory system and skin. S-phrases. S23 Do not inhale vapor. S24/25 Avoid contact with eyes and skin. S26 in case of contact with eyes, rinse thoroughly immediately with water and consult a doctor.



3. Installation of the tag

Select the position where you would like to install the tag. Press the tool holding the tag onto the equipment casing. The adhesive strip around the edge of the tag adheres to the surface stopping any excess glue from escaping.



4. Installation completed

Remove the tool and the marking process is complete!



Do you have any queries? Do not hesitate to contact us!